Interrupts

In order to provide faster response to external events, while avoiding inefficient *busy wait*, most CPUs provide an interrupt request line for use by I/O devices.



The assertion of the interrupt request line by an I/O device should initiate an interrupt cycle.

Interrupt Cycle

- Disable interrupts
- Store PC
- Jump to service routine
  - Determine source of interrupt
  - Service interrupt
  - Clear interrupt
  - Return from interrupt
- Enable interrupts

6809 Interrupts

The 6809 processor provides a number of interrupt request lines with differing functionality.



The simplest is the Fast Interrupt Request line, $\overline{FIRQ}$.
We shall consider the interrupt cycle initiated by asserting $\overline{FIRQ}$.

6809 Interrupt Cycle

- `FIRQ`
  - Push PC onto system stack

    SP$\Downarrow$ PC　　　　SP$\Downarrow$ PC_L

    　　　　　　　　　　SP$\Downarrow$ PC_H

  - Push CCR onto system stack

    Clear E[1]

    SP$\Downarrow$ CCR

  - Disable interrupts

    Set F,I

  - Jump to service routine

    PC $\leftarrow$ (FFF6):(FFF7)

[1] E = 0 indicates a *fast* interrupt.

6809 Interrupt Cycle

- `RTI`
  - Restore CCR (and hence enable interrupts)

    $\mathtt{SP} \Uparrow \mathtt{CCR}$
  - Check for fast interrupt

    `IF (E == 0)`
    - - Restore PC

      $\mathtt{SP} \Uparrow \mathtt{PC}$

      $\mathtt{SP} \Uparrow \mathtt{PC}_H$

      $\mathtt{SP} \Uparrow \mathtt{PC}_L$
  - Otherwise ...

    `IF (E == 1)`

    ...

    ...

6809 Interrupt Cycle

The diagram below illustrates the sequence of events for an FIRQ request including:

- The stacking of the program counter and condition code registers.
- The indirection via the FIRQ interrupt vector, (FFF6):(FFF7).



Interrupt Cycle

Use of registers

The interrupt should not affect the interrupted code. Thus any registers used by the interrupt service routine must be saved.

Where this is not done automatically by the processor it is the responsibility of the service routine.

- **Store registers**
- *Determine source of interrupt*
- *Service interrupt*
- *Clear interrupt*
- **Restore registers**
- *Return from interrupt*

6809 Interrupt Cycle

- IRQ
  - Push PC onto system stack

    `SP⇓ PC`
  - Push other registers onto system stack

    `SP⇓ U,Y,X,DPR,B,A`
  - Push CCR onto system stack

    `Set E`[2]

    `SP⇓ CCR`
  - Disable interrupts

    `Set I`
  - Jump to service routine

    `PC ← (FFF8):(FFF9)`

[2] E = 1 indicates that the *entire* state has been saved. RTI checks this flag and restores registers accordingly.

6809 Interrupt Priority

Each service routine automatically disables interrupts of the same or lesser priority.

6809
Condition Code
Register



- IRQ *low priority*
  sets `I=1` disabling only IRQ requests.
- FIRQ *high priority*
  sets `F=1` and `I=1` disabling FIRQ and IRQ requests.

Masks are reset when CCR is restored from stack by RTI.

6809 Interrupt Priority

The 6809 supports a third interrupt line:

- NMI *highest priority*
  - Non-Maskable Interrupt Request
  - Saves entire state and sets `E=1` like IRQ.
  - NMI sets `F=1` and `I=1` disabling FIRQ and IRQ requests.
  - There is no interrupt mask for an NMI request.
  - An NMI event will interrupt any process (including another NMI service routine).

6809 Interrupt Priority

Non–Maskable Interrupts

- This interrupt is used for the most urgent tasks, which cannot wait for other interrupt routines to complete.
- Since we cannot disable this interrupt, we must find an other method of preventing recursive service routine calls as a result of a single event.
  - The NMI event is triggered by a *falling edge* on the $\overline{NMI}$ line.
  - The action of clearing the interrupt will enable subsequent interrupts.
  - We must consider the possibility of overlapping NMI requests[3].

[3] e.g. poll NMI devices again after clearing the source of an interrupt

Sharing an Interrupt Line

It is seldom possible to have one interrupt line per I/O device.



Note: The wire-OR here is actually a wire-AND of negated signals

Sharing an Interrupt Line

- Determining the source of an interrupt

  Polling

  – The processor must poll each I/O device[4] connected to the line.
  – This may be very time-consuming where many devices share the same IRQ line.

  Priority

  – The order of polling determines the priority where multiple devices are awaiting service.

[4] i.e. read the I/O device *status register*

Sharing an Interrupt Line

Nested interrupts

In order to avoid blocking important events we may wish to re-enable interrupts on the same line before an interrupt routine completes.

- *Determine source of interrupt*
- **Clear interrupt**
- **Enable interrupts**
- **Service interrupt**
- *Return from interrupt*

Note: Where request lines are level sensitive, we must clear the source of an interrupt before re-enabling interrupts in order to avoid an endless recursion.

Sharing an Interrupt Line

Nested interrupts

Alternatively, where one part of the routine is particularly time critical, interrupts may be enabled after this code has completed.

- *Determine source of interrupt*
- **Time critical interrupt service**
- *Clear interrupt*
- *Enable interrupts*
- **Rest of interrupt service**
- *Return from interrupt*

6809 Interrupt Masks

The 6809 allows direct manipulation of the control bits in the CCR.[5]



- Interrupt masks may be set or cleared explicitly by the user.
  - `ANDCC #10111111`$_2$ will enable FIRQ events.
  - `ORCC #01010000`$_2$ will disable IRQ & FIRQ events.

[5]Note that greater selectivity may be achieved by masking an interrupt at source, but this is rather dangerous; only the routine responsible for the management of an I/O device should manipulate its interrupt mask.

Interaction with I/O Device

- Interrupt Request asserted by I/O Device
  - request will remain active until explicitly cleared
- Service Routine queries I/O Device
  - read from status register
    - - whether the device interrupt is active
    - - what is the cause of an active interrupt[6]
- Service Routine services interrupt
  - e.g. reads data from I/O device
- Service Routine clears interrupt
  - Device dependent – consult device data sheet

[6] a single device may have several interrupts active concurrently

Clearing of Interrupts

Consider our imaginary asynchronous receiver/transmitter device:



Clearing of Interrupts

- The device generates the interrupt request from a logical AND of the Status Register and the Interrupt Mask Register.



- The device supports two interrupts
  - data arrived – needs reading
  - data transmitted – send more